


14. Reverse the removal steps to install the front fender.

## HEADLIGHT GRILL

### Removal/Installation



1. Remove the headlight housings as described in the *Headlight Lens* section in Chapter Nine.
2. Remove the mounting screws and retaining clips.
3. Remove the headlight grill.
4. Reverse the removal procedure to install the headlight grill.



## REAR CARRIER

### Removal/Installation





1. Park the ATV on level ground and set the parking brake.
2. Remove the bolts (A, **Figure 19**) securing the rear fender to the carrier on each side.
3. Remove the bolts (B, **Figure 19**) securing the rear carrier to the frame on each side.
4. Remove the rear carrier (**Figure 20**).
5. Install the rear carrier by reversing the preceding removal steps.



## REAR FENDER

### Removal/Installation

1. Park the ATV on level ground and set the parking brake.
2. Remove the rear carrier as described in this chapter.
3. Remove the battery (Chapter Three).



4. Pull off the black rubber boot on the starter relay, then disconnect the starter motor lead from the starter relay terminal (A, **Figure 21**). With the starter relay in place, remove the mounting bracket screw and remove the relay and bracket.

5. Remove the upper connector (B, **Figure 21**) from the mounting bracket. Use a thin-blade screwdriver and push forward the tab on the connector (**Figure 22**) to disengage it from the mounting bracket.

6. Disengage the fuse box (C, **Figure 21**) from the mounting bracket by pushing forward the retaining tab with a thin-blade screwdriver (**Figure 23**). Lift the fuse box off the bracket.

7. Remove the lower connector (D, **Figure 21**) from the mounting bracket. Use a thin-blade screwdriver and push up the tab on the connector to disengage it from the mounting bracket.

8. Detach the wiring harness clamp (E, **Figure 21**).

9. On FM/TM models, remove the rear mud guards as described in this chapter.

10. On FE/TE models, remove the center mud guards as described in this chapter.

#### CAUTION

*If the muffler is hot, do not allow the rear fender to contact it.*

11. Remove the retaining clips.

12. Remove the rear fender while directing the electrical wires through the opening in the rear fender.

13. Reverse the removal procedure to install the rear fender.

### TOOL BOX

#### Removal/Installation

1. Remove the rear fender as described in this chapter.

2. Disconnect the taillight connectors (A, **Figure 24**).

3. Remove the mounting screws (B, **Figure 24**) on each side, then remove the tool box.

4. Reverse the removal procedure to install the rear fender. Be sure to install the collars on the mounting screws.

Copyright of Honda TRX350 RANCHER, 2000-2006 is the property of Penton Media, Inc. ("Clymer") and its content may not be copied or emailed to multiple sites or posted to a listserv without the copyright holder's express written permission. However, users may print, download, or email articles for individual use.